

# VISTA

Thermal Imaging Monocular



## User Manual

VISTA S50R / VISTA H50R / VISTA H50  
VISTA H35R / VISTA H35

V2.0

# 1 Specification

Model	VISTA H35	VISTA H35R	VISTA H50	VISTA H50R	VISTA S50R
Thermal Sensor	640×512,12μm				1280×1024,12μm
NETD,mK	≤15				
Frame rate,Hz	60				
Objective lens,mm	35 F0.9		50 F0.9		50 F0.9
Field of view(H×V),°/m@100m	12.5×10.0/22×18		8.8×7.0/15×12		17.5×14.0/31×25
Magnification,x	3~28		4~40		2~40
Detective range,m (Target size:1.7m×0.5m,P(n)=99%)	1800		2600		2600
Exit relief,mm	25		25		25
Exit pupil diameter,mm	8		8		8
Diopter,D	-4~+6		-4~+6		-5~+3
Display	AMOLED 2560×2560				
Battery Type	Replaceable li-ion battery pack IBP-7/4400mAh				
Max.operation time,(t=22°C)h	5.5				4.5
Safety Class for Laser	/	Class 1	/	Class 1	Class 1
Max.Rangefinder distance,m	/	1200	/	1200	1200
MIC	Support				

Memory capacity,GB	64				
IP rating	IP67				
Operating temperature,°C	-20 ~ +50				
Weight,g(with battery)	600	640	630	650	690
Dimension,mm	184×61×71	190×67×79	190×67×79	194×70×82	201×70×82

- ★ The actual operating time depends on the density of Wi-Fi use, photographing, video recording, etc.
- Improvements may be made to the design and software of this product to enhance its features without prior notice to the customer.

## 2 Package Contents

- VISTA series Thermal Imaging Monocular
- Portable bag
- Battery pack IBP-7 × 2
- Data cable
- Neck Strap
- Lens cleaning cloth
- Quick start guide

## 3 Description

The Vista series thermal imaging monoculars are designed for use both at night-time and during the day and provide exceptional image quality even in adverse weather conditions (fog, smog, rain) and beyond obstacles like branches, tall grass, dense foliage, etc. known to hinder target detection.


VISTA thermal imagers are designed for various applications including hunting, observation, security, terrain orientation, search and rescue operations, etc.

## 4 Features

- 1280×1024 or 640×512 12μm detector
- NETD≤15mK
- 60Hz high frame rate
- F0.9 objective lens
- Lens and Laser rangefinder 2 in 1(VISTA H35R/VISTA H50R/VISTA S50R)
- AMOLED 2560×2560 round display
- Rechargeable Battery pack IBP-7 for quick replacement
- Smooth digital zoom
- Ultra clear mode
- Eye protection with low brightness, color palette and warm hue
- Electronic image stabilization



# 5 Components and Buttons



1.lens cap

2. Lens focus ring

3. Laser rangefinder (H35R/H50R)

4. Power (P) button

5. Up button

6. Menu (M) button








7. Down button

8. Battery Pack

9. Eyepiece

10. Eyeshade

## 6 Button Operations


Button	Current Status	Short Press	Press and Hold
<b>Power button</b> 	Powered off	---	Power on the device
	Home screen	Standby the device	Power off the device
	Standby mode	Wake up the device	Wake up the device
	Shortcut menu interface	Return to the upper menu with saving changes	Power off the device
	Main menu interface	Return to the upper menu without saving changes	Power off the device
<b>Up button</b> 	Home screen	Digital zoom	Turn on/off the LRF function
	Shortcut menu interface	Navigation upwards	---
	Menu interface	Navigation upwards	---
<b>Menu button</b> <b>M</b>	Home screen	Open the shortcut menu	Go to the main menu
	Shortcut menu interface	Enter the parameters selection state / confirm	Save and back to the home screen
	Main menu interface	Enter the submenu / Switch and confirm parameters	Save and back to the home screen
<b>Down button</b> 	Home screen	Take a photo	Start a video recording
	Video recording	Take a photo	Stop and save the video
	Shortcut menu interface	Navigation downwards	---
	Menu interface	Navigation downwards	---
 + <b>M</b>	Home screen	---	Turn on/off PIP
 + 	Home screen	Shutter calibration	Background calibration
<b>M</b> + 	Home screen or Laser rangefinder	---	Switch the ranging mode between <b>single</b> ranging and <b>continuous</b> ranging

## 7 Battery charging


The Vista series uses the rechargeable lithium-ion Battery pack. Please charge the Battery before use.


### Method 1: Charging directly

- Connect the Type-C plug of the data cable to the port of the battery pack.
- Connect the other plug of the data cable to the USB port of the power adapter.
- Insert the power adapter to a 100V - 240V power socket to charge the Battery.
- During the charging process, the LED indicator on the Battery pack will start to glow and blink. If all four indicator lights are on and stationary, the Battery is fully charged.



### Method 2: Charging with Type-C Port




- Open the Type-C port cover on the bottom of the Vista series.
- Connect the Type-C end of the data cable to the Type-C port.
- Connect the other end of the data cable to the power adapter.
- Plug the adapter into a 100-240v power socket for charging.
- The battery icon will be changed to the charging icon  on the display.
- During charging the Battery with the Type C port, the status light on the Vista series will change also to display the battery status.
  - If the status light is steady red, the Battery is being charged.
  - If the status light turns green, the Battery is fully charged.



## Battery Pack Installation

- Slide the button on the battery compartment cover, open the battery compartment, and pull out the battery pack
- Insert the battery pack, cover the battery compartment cover, and slide the button to lock it.





## Precautions for Battery

- After a long storage time, the battery should be partially charged, not fully charged or discharged.
- Do not charge the battery immediately after you bring it from the cold environment to the warm environment. Wait 30 to 40 minutes for it to warm up.
- Do not charge the battery unsupervised.
- Charge the battery in the environment of 0°C to +45°C. Otherwise, the service life of the battery will be reduced.
- Charging time should not exceed 24 hours.
- Do not expose the Battery to high temperature or a naked flame.
- Do not immerse the Battery in water.
- Do not connect external device with a current consumption that exceed permitted levels.
- The Battery is equipped with a short circuit protection function. However, any situation that may cause short-circuiting should be avoided.
- Please do not disassemble or modify the Battery without professional instructions.
- Do not knock or drop the Battery.
- The battery capacity may decrease when using the battery in negative temperature, that is normal, not a defect.

- Avoid using the Battery at the temperature above the temperature shown in the table, this may decrease the battery pack's life.
- Please keep the Battery out of the reach of children.

## 8 External Power Supply

The Vista series can be powered with an external power supply, such as a Power Bank (5V).

- Connect the external power supply to the Type-C port on the bottom of the Vista series.
- The device will switch to the external power supply and charge the internal Battery Pack at the same time.
- The battery icon will be changed to the charging icon  .
- If the device is connected to an external power source and no Battery Pack is installed, the battery icon will be changed to the USB icon .
- When the external power supply is disconnected, the Vista series will automatically switch to the Battery Pack without powering off.

## 9 Power On/Off and Image Settings

- Power On: Remove the lens cap. Press and hold the **Power button** to power on the device. Then, the home screen is displayed after several seconds.
- Rotate the eyepiece diopter ring until the image becomes clear in the eyepiece. After the adjustment, it no needs to be adjusted for the same user.
- Rotate the focusing ring of the objective lens to focus on the object to be observed.
- To set the image mode, display brightness, image sharpness, image contrast, refer to the **Shortcut Menu** section in this manual.
- Power Off: After use, press and hold the **Power button** and a shutdown countdown is displayed. Then release your finger. During the process, press any key can cancel the shutdown.

## 10 Update and NOCPIX APP

### Client Software Connection

The Vista series thermal imaging monocular supports control with **NOCPIX** App, which allows you to transmit images in real time, operate the device, and update the program by connecting a smartphone or laptop via Wi-Fi.

You can download and install the NOCPIX App In the official website (www.nocpix.com) or the app store. Alternatively, you can scan the QR code below to download it for free.





The vista series has a built-in Wi-Fi module. The device can connect to an external apparatus (computer or mobile phone) via Wi-Fi.

- In the home screen, press and hold the **M button** to go to the main menu. enable the Wi-Fi on the device.
- After the Wi-Fi is enabled, search for the Wi-Fi named **VISTA\_H50R\_XXXXXXX** on the external device, among which XXXXXXXX is the serial number of the device. Select the Wi-Fi, enter the password and connect. The initial password is **12345678**.
- After the Wi-Fi connection is established, you can control the device via the mobile app.
- Through the APP, many functions can be achieved, such as upgrade device、 real-time image transmission、 device file and date&time calibration.



### Upgrade Device


- When installation completed, open NOCPIX application.
- If your device has been connected to a mobile device, please switch on the mobile data in mobile device. After connection, an update prompt will be displayed automatically in the APP. Click **Now** to download the latest version immediately or click **Later** to update later.
- **NOCPIX** can store the last connected device automatically. Therefore, once you have connected with **NOCPIX** before, it will automatically detect the update even when the scope is not connected to a phone or laptop.
- If an update is available and the mobile device accesses the internet, you can download the update first. Then when the device is connected with the mobile device, it will be updated automatically. After the update is installed, the device will restart automatically.



# 11 Shortcut Menu

On the shortcut menu, you can quickly adjust basic configurations of commonly used functions, including the image mode, display brightness, image sharpness, and image contrast.

- In the home screen, press the **M button** to go to the shortcut menu.
- Press the **Up / Down** button to switch the following options.
  - **Image mode:** : Press **M button** to switch state, press **up/down button** to select image mode.
  - **Image brightness:** Press the **M button** to switch state, press **up/down button** to change the image brightness from level 1 to level 10.
  - **Image sharpness:** Press the **M button** to switch state, press **up/down button** to change the image sharpness from level 1 to level 10.
  - **Image contrast:** Press the **M button** to switch state, press **up/down button** to change the image contrast from level 1 to level 10.
- Press and hold the **M button** to save the changes and return to the home screen.
- In the shortcut menu, if there is no operation within 7s, the device will automatically save the changes and return to the home screen.







## 12 Main Menu





- In the home screen, press and hold the **M button** to go to the main menu.
- Press the **Up / Down** button to switch the menu options.
- The function options in the main menu are cyclical: when the arrow > reaches the last option on the first page, it will turn to the first menu option on the second page. When the arrow > is on the first option of the first page, press the **Up** button to switch to the last option of the second page.
- Press the **M button** to modify the parameter settings of the current menu option or to open the submenu.
- In the second and third-level submenu, press the **Up / Down** button to choose a parameter or function; press the **M button** to confirm the selection. An icon flashes, indicating the changes are being saved, and then the upper menu or the submenu is displayed.
- In any menu interface, press the **Power button** to return to the upper menu or home screen without saving the changes, and press and hold the **M button** to save the changes and return to the home screen.
- In any menu interface, the device will automatically return to the home screen without saving the changes when there is no operation within 15s.
- During the continuous operation of the thermal imaging monocular, when you exit from the main menu, the cursor > remains at the position before exiting. When you restart the thermal imaging monocular and go to the main menu for the first time, the cursor stays at the first menu option.








## Main Menu Options and Descriptions

<p><b>Picture In Picture</b></p> 	<p><b>Turn the PIP on/off</b></p> <ul style="list-style-type: none"> <li>● Press and hold down the <b>M</b> button to enter the main menu.</li> <li>● Turn the PIP on /off with a short press of <b>M</b> button.</li> <li>● Picture-in-Picture (PIP) provides a floating window independent of the full screen. This window shows part of the image which is enlarged to 2× in a certain area centered on the reticle of the main image.</li> </ul>	
<p><b>Ultra-clear</b></p> 	<p><b>Turn the Ultra-clear mode on/off</b></p> <ul style="list-style-type: none"> <li>● Press and hold down the <b>M</b> button to enter the main menu.</li> <li>● Select the <b>Ultra-clear</b> menu option with the <b>Up / Down</b> button.</li> <li>● Turn the Ultra-clear mode on /off with a short press of <b>M</b> button, during which you will hear a click of shutter calibration.</li> <li>● When the function is turned on/off, the icon on the status bar changes accordingly.</li> <li>● When the Ultra-clear mode is on, the image contrast is enhanced, which is suitable for rainy, foggy and other harsh weather conditions.</li> </ul>	

<p><b>Wi-Fi</b></p> 	<p><b>Turn Wi-Fi on/off</b></p> <ul style="list-style-type: none"> <li>● Press and hold down the <b>M</b> button to enter the main menu.</li> <li>● Press the <b>Up / Down</b> button to select the <b>Wi-Fi</b> option.</li> <li>● Turn the Wi-Fi on /off with a short press of <b>M</b> button.</li> <li>● When Wi-Fi is on, the default password is prompted for 3s behind the icon of Wi-Fi.</li> <li>● The default password is <b>12345678</b>. After the password is changed, it will not be displayed.</li> <li>● When the function is turned on/off, the icon on the status bar changes accordingly.</li> </ul>	
<p><b>Image Hue</b></p> 	<p><b>Set the image hue</b></p> <ul style="list-style-type: none"> <li>● Press and hold down the <b>M</b> button to enter the main menu.</li> <li>● Press the <b>Up / Down</b> button to select the <b>Image Hue</b> option.</li> <li>● Press the <b>M</b> button to switch the <b>Image Hue</b> between <b>W</b> (warm) and <b>C</b> (cool).</li> <li>● Cool hue image is brighter and warm hue image is softer and eye protection.</li> <li>● The switch between the warm and cool hues is not applicable to the color palettes.</li> </ul>	

<p><b>Microphone</b></p> 	<p><b>Turn MIC on/off</b></p> <ul style="list-style-type: none"> <li>● Press and hold down the <b>M</b> button to enter the main menu.</li> <li>● Press the <b>Up / Down</b> button to select the <b>MIC</b> option.</li> <li>● Press the <b>M</b> button to turn MIC on/off.</li> <li>● After MIC is on, the device will record sound during video recording.</li> </ul> 
<p><b>Calibration</b></p> 	<p><b>Set the calibration mode</b></p> <p>In rare cases, once the image is degraded or uneven, it can be improved by calibration. There are two calibration modes: Automatic and Manual. Regardless of which mode you are in, you can manually operate Shutter calibration and background calibration.</p> <ul style="list-style-type: none"> <li>● Press and hold down the <b>M</b> button to enter the main menu.</li> <li>● Press the <b>Up / Down</b> button to select the <b>Calibration</b> option.</li> <li>● Press the <b>M</b> button to enter the submenu of the <b>Calibration</b> function.</li> <li>● Press the <b>Up / Down</b> button to switch the selection between <b>Automatic</b> and <b>Manual</b>. <ul style="list-style-type: none"> <li>- <b>Automatic Calibration:</b> It is defined by software algorithms. When the Image quality deteriorates, it will be calibrated automatically in this mode.</li> <li>- <b>Manual Calibration:</b> Images are calibrated by the user according to the image effect. You need to press the <b>Up button + Down button</b> at the same time to perform the calibration.</li> </ul> </li> </ul>



- Press the **M** button to confirm your selection. The icon on the status bar changes accordingly.



Shutter Calibration

Background Calibration



### View video/photo files in the device

- Press and hold down the **M** button to enter the main menu.
- Press the **Up / Down** button to select the **Gallery** option.
- Press the **M** button to enter the **Gallery** function.
- When there are a large number of files, there is a file cache time after entering the function
- In each interface, the operation logic of the buttons is as follows

### Gallery



		<b>Folder interface</b>	<b>File interface</b>	<b>View interface</b>
<b>Power button</b>	Short press	Return to the upper menu	Return to the upper menu	Return to the upper menu
<b>Up button</b>	Short press	Navigation upwards	Navigation upwards	Backward
	Press and Hold	Previous page	Previous page	/
<b>Menu button</b>	Short press	Enter folder	View file	Pause/Play
	Press and Hold	Back to the home screen	Back to the home screen	Back to the home screen
<b>Down button</b>	Short press	Navigation downwards	Navigation downwards	Fast forward
	Press and Hold	Next page	Next page	/

**Setting the general settings**

- Press and hold down the **M** button to enter the main menu.
- Press the **Up / Down** button to select the **Settings** option.
- Briefly press the **M** button to enter the submenu.
- This menu item allows you to configure the following settings.

**Settings**











**Date**




**Setting the system date**

- In the **Settings** submenu, select the **Date** menu option with the **Up / Down** button.
- The date is in the format of **YY/MM/DD**.
- Briefly press the **M** button to active the **Date** submenu. Two triangle icons will appear above and below the value.
- Switch among the year, month, and day with a short press of the **M** button.
- Set the correct year, month, and day with a short press of the **Up / Down** button.
- Press and hold down the **M** button to save and exit.

<p style="text-align: center;"><b>Time</b></p> 	<p><b>Setting the system time</b></p> <ul style="list-style-type: none"> <li>● In the <b>Settings</b> submenu, select the <b>Time</b> menu option with the <b>Up / Down</b> button.</li> <li>● The time format is displayed as <b>HH:MM</b> in 24-hours format.</li> <li>● Press the <b>M</b> button to active the <b>Date</b> submenu. Two triangle icons will appear above and below the value.</li> <li>● Select the correct value for the hour and minute with a short press of the <b>Up / Down</b> button.</li> <li>● Short press the <b>M</b> button to switch between hour and minute.</li> <li>● Press and hold down the <b>M</b> button to save and exit. And the time in the status bar changes accordingly.</li> </ul>
<p style="text-align: center;"><b>Language</b></p> 	<p><b>Setting the system language</b></p> <ul style="list-style-type: none"> <li>● In the <b>Settings</b> submenu, select the <b>Language</b> menu option with the <b>Up / Down</b> button.</li> <li>● Enter the <b>Language</b> submenu with a short press of the <b>M</b> button.</li> <li>● Select the desired language with a short press of the <b>Up / Down</b> button.</li> <li>● Press the <b>M</b> button to confirm the selection. At the same time, it will save setting and exit to the Settings submenu automatically.</li> </ul>
<p style="text-align: center;"><b>Status Bar</b></p> 	<p><b>Setting UI</b></p> <ul style="list-style-type: none"> <li>● In the <b>Settings</b> submenu, select the <b>Status Bar</b> menu option with the <b>Up / Down</b> button.</li> <li>● When Select Hide, UI only retains time、 magnification and battery level icons, When Show is selected, all icons are displayed.</li> </ul>

	
<p><b>Unit</b></p> 	<p><b>Distance measurement unit</b></p> <ul style="list-style-type: none"> <li>● In the <b>Settings</b> submenu, select the <b>Unit</b> menu option with the <b>Up / Down</b> button.</li> <li>● You can choose units of m or yr</li> </ul>
<p><b>EIS</b></p> 	<p><b>Turn Electronic Image Stabilization on/off</b></p> <ul style="list-style-type: none"> <li>● In the <b>Settings</b> submenu, select the <b>EIS</b> menu option with the <b>Up / Down</b> button.</li> <li>● Press the <b>M</b> button to turn EIS on/off</li> <li>● When EIS is turned on, the image will be slightly enlarged.</li> <li>● When the laser rangefinder is turned on, EIS is turned off by default.</li> </ul> 
<p><b>Factory Reset</b></p> 	<p><b>Restoring factory default settings</b></p> <ul style="list-style-type: none"> <li>● In the <b>Settings</b> submenu, select the <b>Factory Reset</b> menu option with the <b>Up / Down</b> button.</li> <li>● Press the <b>M</b> button to enter the <b>Factory Reset</b> submenu.</li> </ul>

		<ul style="list-style-type: none"> <li>● Press the <b>Up / Down</b> button to select Yes or No. <b>Yes</b> means to restore factory settings and <b>No</b> means to cancel the operation.</li> <li>● Confirm your selection with a short press of the <b>M</b> button.</li> <li>● If <b>Yes</b> is selected, the thermal imaging monocular will reboot automatically.</li> <li>● If <b>No</b> is selected, the operation is canceled and the screen returns to the upper menu.</li> </ul> <p>After the Factory Reset is selected, the following functions will be restored to default settings:</p> <ul style="list-style-type: none"> <li>- <b>Image mode:</b> white hot</li> <li>- <b>Ultra-clear mode:</b> off</li> <li>- <b>Display brightness:</b> level 5</li> <li>- <b>Wi-Fi:</b> off</li> <li>- <b>Image sharpness:</b> level 5</li> <li>- <b>Image Hue:</b> C</li> <li>- <b>Image contrast:</b> level 5</li> <li>- <b>MIC:</b> off</li> <li>- <b>Digital zoom:</b> 1×</li> <li>- <b>Calibration mode:</b> A</li> <li>- <b>Status Bar:</b> Show</li> <li>- <b>Unit:</b> m</li> </ul>
	<p style="text-align: center;"><b>Info</b></p> 	<p><b>Showing the system information</b></p> <ul style="list-style-type: none"> <li>● In the <b>Settings</b> submenu, select the <b>Info</b> menu option with the <b>Up / Down</b> button.</li> <li>● The relevant information of device will be shown by a short press of the <b>M</b> button.</li> <li>● This item allows the user to view the following information of the current thermal imaging monocular: product model, Firmware, PN, SN, hardware version number, etc.</li> <li>● Press and hold the <b>M</b> button to return to the General Settings submenu.</li> </ul>

## 13 Digital Zoom


The Vista series supports quick digital zoom-in for images, to increase visual magnification.

- On the home screen, press the **Up button** to zoom the image.
- The corresponding magnification is displayed in the status bar.


## 14 Photographing and Video Recording

The Vista series thermal imaging monocular is equipped with a built-in 64GB memory storage and supports photographing and video recording. The image and video files will be named after time, so it is recommended to set the system date and time in the Main Menu before using the photo and video functions (refers to **Main Menu - Settings - Date/Time Setting** in this manual), or to synchronize the system date and time in the settings of the NOCPIX App. For details, refer to the Operating Instructions for the App in our official website ([www.nocpixr.com](http://www.nocpixr.com)).


### Photographing

- On the home screen, press the **Down button** to take a photo. The image freezes for 0.5 sec with a camera icon  flash on the upper left

corner. After the image is taken, the icon disappears.

- The images taken are saved in the built-in memory storage.
- When the exclamation mark icon  appears on the right side of the camera icon, it prompts that the memory space is insufficient. Check and transfer your videos and images to other media to free up the space.

### Video Recording

- On the home screen, press and hold the **Down button** to start the video recording.
- The recording icon  and recording time prompt are displayed on the upper left corner of the display, and the time is in the format of HH:MM:SS (hour: Minute: Second).
- The red dot on the left of the time prompt will flash continuously when recording.
- During recording, you can also take a photo by pressing the **Down button**.
- Press and hold the **Down button** to stop and save the video. Recording.
- All videos and photos will be saved in the built-in memory storage.
- Vista series is built-in Microphone function, You can turn on the microphone function to record while recording.

- You can enter and work on the menu during video recording.
- The image taken and the recorded video will be respectively saved in the names in the formats of IMG\_yyyyMMddHHmmss.jpg and VID\_yyyyMMddHHmmss.mp4 in the built-in memory card (yyyyMMddHHmmss-year, month, date, hour, minute, and second);
- Due to the limitation of the storage space, it is recommended that you clean the memory regularly or move the images and videos to other storage medium to release memory space of the device.

## Memory Access

When the device is powered on and connected to a computer, it will be recognized by the computer as a flash memory card. Then, you can access the memory of the device and copy images and videos.

- Connect the device to a computer through the data cable.
- Power on the device.
- Double-click "My Computer" on the desktop - double-click to open the device named "NOCPPIX"- then double-click to open the device name "VISTA" to access the memory.
- Files named by time will be displayed after you access the memory.

## 15 Laser Rangefinder (VISTA H35R/VISTA H50R/VISTA S50R)

- In the home screen, press and hold the **Up** buttons to turn the laser rangefinder function on/off.
- You can change the unit of distance measurement by using the unit function in the settings menu.
- Long press the **Up** button to exit to the laser rangefinder function.
- You can switch the ranging mode between continuous ranging(**CONT**) and single ranging(**SGL**) by long pressing **M+ ↓**. When in single ranging mode, press the **up** button to get SGL distance, The distance measurement display disappears after 10 seconds.

## 16 Technical Inspection

Perform a technical inspection to check the following items each time before you use the device:

- Exterior of the device (no crack on the enclosure).
- Lens and eyepiece (no crack, oil, stain, or other sediments)
- Status of the rechargeable battery (fully charged in advance) and electrical contact (no salinization or oxidation).

## 17 Maintenance

The maintenance should be carried out at least twice a year and includes the following steps:

- Wipe the surface of metal and plastic parts to clear off dust and dirt with a cotton cloth. Silicone grease may be used for cleaning process.
- Clean the electric contacts and battery slots on the device using a non-greasy organic solvent.
- Check the glass surface of the eyepiece and lens. If necessary, clear off the dust and sand on the lens (it is perfect to use a non-contact method). Use a specialized wiping tool and solvent to clean the optical surfaces.



## 18 Troubleshooting

The following table lists all problems that are likely to occur during device operation. Check and address problems by referring to this table. If faults not included in this table occur or you cannot fix the fault, return the device to the vendor or supplier for troubleshooting.

Faults	Possible Causes	Solutions
The device cannot start.	The battery is out of charge	Charge the battery
The device cannot be powered by an external power supply	The USB cable is damaged	Replace the USB cable
	The external power supply is insufficient	If necessary, check the external power supply
Images are too dark	The display is not bright enough	Adjust the display brightness
The image quality is poor or the detection range shortens	These problems are likely to occur when you use the device in harsh weather (such as snow, rain, and fog).	
The device cannot connect to a smartphone or computer	The Wi-Fi password is incorrect	Enter the correct password
	There are too many Wi-Fi networks in the range of the device, which may cause interference	To enable stable network access, you are advised to move the device to an area with a limited number of Wi-Fi networks, or an area without Wi-Fi coverage
Wi-Fi signals are lost or interrupted.	The device is beyond Wi-Fi coverage. There is blocking (such as concrete walls) between the device and the receiver.	Move the device to a place where you can receive Wi-Fi signals.
When the device is used at a low temperature, the imaging quality is poorer than that at normal temperature.	At temperatures above 0°C, the temperature rise varies with the observed objects (environment and background) due to different heat conductivity coefficients. As a result, high-temperature contrast occurs and the image quality is better. At low temperatures, the observed targets (background) usually cool down to a similar temperature because of reduced temperature contrast. Therefore, the image quality (details in particular) is poor, which is a characteristic of thermal imaging devices.	

## 19 Legal and Regulatory Information

Wireless transmitter module frequency range:

**WLAN: 2.412-2.472GHz (for EU)**

Wireless transmitter module power < 20dBm (only for EU)



We, Inlumen Technologies Co., Ltd. hereby declares that the radio equipment Mate series is in compliance with the Directives 2014/53/EU and 2011/65/EU

### FCC Statement

**FCC ID: 2BHFB-3C-00**

#### Labeling requirements

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### Information to the user

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### EMC: Class A


**Note:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

To comply with RF exposure requirements, a minimum separation distance of 0.00 cm must be maintained between the user's body and the handset, including the antenna.



 **Manufacturer:** Inlumen Technologies Co., Ltd.

 **E-mail:** [service@nocpix.com](mailto:service@nocpix.com)

 **Website:** [www.nocpix.com](http://www.nocpix.com)

 **Address:** North 6F, Building B3, Hefei Software Park, No.800 Wangjiang West Road, Hefei National High-tech Industry Development District, Anhui, China.